


# TAS-256 TAS-8 and SAS-1 to SAS-4 User Manual




## Total Access Switch (TAS-256)


### Switch Panel Control

- To control its own zone from Switch pad button
  - Press 1-8 button to toggle on/off

- To control other zone




- Press "NEXT" button (right) to forward to next box in the network or



- Press "PREV." button (left) to back to previous box in the network
- Press 1-8 button to toggle on/off from the selected zone

- To jump to control other zone




- Press and hold "NEXT" button until ( \_ \_ ) is shown on the Switch Panel
- Key in 2 digit Box ID (Ex. 04 for Box ID No. 4)  
(Now Box No. 4 will be active)

### Remote Control - Point Remote to Switch Panel



- To control its own zone



- Press 1-8 button to toggle on/off
- To control other zone




- Press "NEXT" button to forward to next box in the network or




- Press "BACK" button to back to previous box in the network
- Press 1-8 button to toggle on/off from the selected zone

- To jump to control other zone



- Press “Select” button until ( \_ \_ ) is shown on the Switch Panel
- Key in 2 digit Box ID (Ex. 04 for Box ID No. 4)  
(Now Box No. 4 will be active)

## Total Access Switch (TAS-8)




### Switch Panel Control

- To control its own zone from Switch pad button
  - Press 1-8 button to toggle on/off

### Remote Control - Point Remote to Switch Panel

- To control its own zone
  - Press 1-8 button to toggle on/off

## Selectable Assign Switch (SAS-1 to SAS-4)



- Press button (1-4) to toggle on/off  
(LED indicates the light is on or Option: Dual LED indicates light is on or off)